


# CONTROL PANEL PARTS

For Models: MH1170XSB3  
(BLACK)

Microwave Oven  
1.7 Cu. Ft.




Illus. No.	Part No.	DESCRIPTION
1	W10110883	Literature U & C Guide
	W10132039	Tech Sheet
	8205885	Cook Guide Label
	8206587	Install, Instruct.
2	W10166190	Panel Asy, Control Includes Lens and Membrane Switch Black
3	W10156814	Bracket, Control
4	W10166188	Microcomputer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: MH1170XSB3  
(BLACK)




Illus. No.	Part No.	DESCRIPTION
1	8206395	COMPLETE DOOR Black
2	W10138802	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERIOR AND VENTILATION PARTS

For Models: MH1170XSB3

(BLACK)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERIOR AND VENTILATION PARTS

For Models: MH1170XSB3

(BLACK)


Illus. No.	Part No.	DESCRIPTION
1	W10139751	Reflector, Lamp
2	8206232	Lamp
3	8206374	Holder, Lamp
4	8206229	Filter, Grease
5	8206386	Plate, Bottom
6	8206376	Glass, Lamp
7	8206375	Holder, Glass
8	8206345	Switch, Micro V5P010CG3
9	8206347	Switch, Micro V5P020CG3
10	W10156812	Spring, Interlock
11	W10156811	Plate, Cam
12		Support, Interlock
	8206419	Top
	W10156813	Bottom
13	8206558	Piston Assembly
14	8206180	Screw
15	8206357	Capacitor, 125 V
16	W10163422	Thermistor (PCBA)
17	W10163421	Plate, Side
18	W10163423	Chassis Assembly
19	8206352	Switch, Micro V5P030CG3
20	8184312	Holder, Fuse
21	W10138793	Fuse
22	8206359	Terminal Cvr, Lamp
23	8206379	Thermostat
24	W10165829	Transformer, H.V.
25	W10156817	Bracket, Capacitor
26	W10138798	Capacitor, H.V.
27	W10163432	Diode, H.V.
28	W10163420	Chassis

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AIR FLOW PARTS

For Models: MH1170XSB3

(BLACK)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	8206340	Deflector, Air
2	8206382	Cover, Lamp
3	4393681	Lamp
4	W10163433	Cover, Side Inlet
5	W10114550	Motor, Fan Assy
6	W10138797	Air Guide

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

7	8206230	Filter, Charcoal
8	W10110862	Mounting, Nut (2)
9	W10138800	Air Guide
10	8206624	Filter
11	8169539	Holder, Lamp
12	W10138799	Base Plate, Air Guide
13	W10156815	Brkt-Mntg, Filter


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

14	W10139750	Socket, Motor Wire
15	W10110598	Cover, Terminal
16	8206341	Magnetron
17	8206342	Thermostat
18	W10164716	Plate, Water Proof

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TURNTABLE PARTS

For Models: MH1170XSB3  
(BLACK)



Illus. No.	Part No.	DESCRIPTION
1	8206389	Cover, Inlet Includes Nails and Bushings
2	8206118	Hook, Rack (4)


Illus. No.	Part No.	DESCRIPTION
3	W10138801	Plst. Rivet(4pcs)
4	4393799	Turntable
5	8206227	Ring, Turntable
6	8206228	Driver, Turntable

Illus. No.	Part No.	DESCRIPTION
7	8183953	Motor, Turntable
8	W10149406	Rack
9	W10107790	Washer
10	8206618	Screw
11	W10107780	Spacer (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET AND INSTALLATION PARTS

For Models: MH1170XSB3  
(BLACK)



<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	8206315	Plate, Mounting
2	8206385	Support, Wire Clip
3	8206442	Damper Assembly
4	8206388	Cord, Power

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
5		Case, Outer
	W10163418	Black
6	8206391	Grille, Vent
	Black	
7	W10157207	Plate, Damper

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
<b>Miscellaneous</b>		
	8206614	Installation, Hardware
	8205871	Template, Upper
	W10138802	Screw, Top Mountng
	W10163434	Main Harness
	W10163438	Ground Wire Assy
	8206415	H.V. Wire Assy
	W10107760	Grnd Wire, Filter
	W10163435	HdImp/TT Wire Assy
	W10163436	HV Trnsfrm Wr Assy
	W10163439	Harness Wire, NTC

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST